

# TECHNICAL UPDATES

## "Version 2.2 Firmware Release"

### ADD THIS DOCUMENT TO YOUR OWNER'S MANUAL

## Description

The Version 2.2 firmware adds the following new features to OmniLT, Omni II, and OmniPro II systems:

- Support for the ALC 4-Button Scene Switch Module
- Support for ALC Switch Press Events

## Selecting ALC Activated Events using the 4-Button Scene Switch Module

### Edit Programs When

Select the 1 (WHEN) key, from the *Edit Program* menu, to select the trigger for the program. The display shows:

```
EDIT WHEN  
1=TIMED 2=BUTTON
```

### Button and Event Programs

Select the 2 (BUTTON), from the "Edit When" menu, to set up a program to be activated when a macro button is executed or an event occurs. The user is prompted to specify the button/event that activates the program:

```
BUTTON:  
ENTER BUTTON #=MENU ↓
```

Press the ' #' key to bring up a menu of event button types.

### Control Unit Events / ALC Switch Press Events

When a control unit or ALC Switch Module is turned on or off, or if a pushbutton on an ALC Switch Module or 4-Button Scene Switch Module is pressed, the "When Unit" program is activated.

Press the 1 (CTRL) key to select the "When Command" for a control unit or ALC Switch Module activated event. Additionally, you can specify that the event will only activate when the pushbutton on an ALC Switch or 4-Button Scene Switch Module is pressed.

You are first prompted to enter the desired unit number:

```
UNIT:  
ENTER UNIT ↓
```

The unit may be selected by entering the unit number followed by the ' #' key or by using the arrow keys to scroll through a list of unit names. Next, the desired unit is displayed and you are prompted to specify the event that activates the program:

```
WHEN Porch Light:  
0=OFF 1=ON 2=ALC
```

Press "0" to select when the unit turns off. Press "1" to select when the unit turns on. Press "2" to select when an ALC Switch Module is pressed in the on or off position (locally at the ALC Switch) or when the pushbutton on an ALC 4-Button Scene Switch Module is pressed.

SWITCH:

0=OFF 1=ON 2-5=SW1-SW4

Press "0" to select when the ALC Switch Module is pressed in the off position. Press "1" to select when the ALC Switch Module is pressed in the on position. Press "2-5" (which corresponds to Switch 1-4, respectively) to select when that pushbutton on the ALC 4-Button Scene Switch Module is pressed. Press the '#' key to enter your selection.