



Model 38A15 Table Top Scene Switch Cradle

DESCRIPTION

The HAI 38A15 Table Top Scene Switch Cradle is used to mount the HAI 38A00-1 HLC Scene Switch, 38A00-2 HLC House Status Switch, or 38A00-3 Lumina Mode Switch in a table top application.

Once a qualified technician has installed a 38A00-1 HLC Scene Switch into the 38A15 Table Top Scene Switch Cradle, it can be used to control the lighting scenes in a room. The 38A00-1 HLC Scene Switch can also be controlled in the cradle using an HAI 38A14-1 Scene Switch Remote.

IMPORTANT SAFETY CONSIDERATIONS

1. Read and follow all safety instructions.
2. Only a qualified electrician should perform the installation.
3. Do not use in close proximity to water. If this product comes into contact with water or any other liquid it should be unplugged immediately.
4. Do not use this product if it has been dropped or damaged.
5. The 38A15 is intended for indoor use only.
6. This product is to be installed out of reach of small children to avoid the risk of fire, burns, personal injury or electric shock.
7. To reduce the risk of electric shock this product uses a polarized plug. If this plug does not fit into your home's electrical sockets contact a qualified electrician. Do not alter the plug. Do not use this product with an extension cord unless the plugs are fully inserted.
8. Keep these instructions for reference.

INSTALLATION

1. Remove the two 6-32 x 1 ¼" screws that hold the 38A15 Table Top Scene Switch Cradle together.
2. Insert the stripped end of the power cord through the hole in the 38A15 Table Top Scene Switch Cradle base. The hole is located on the bottom of the tall end of the base of the cradle.
3. Connect the white wire of the 38A00 Series to the ribbed wire of the power cord using one of the wire nuts provided.
4. Connect the black wire of the 38A00 Series Switch to the non-ribbed wire of the power cord using one of the wire nuts provided.
5. Place the 38A00 Series Switch into the 38A15 Table Top Scene Switch Cradle base. The wire nuts should be located in the tall end of the 38A15 Table Top Scene Switch Cradle base.
6. Place the 38A15 Table Top Scene Switch Cradle front over the 38A00 Series Switch and secure it into place using the 6-32 x 1 ¼" screws removed in step one.
7. Install the grommet over the power cord and insert it into the hole in the base of the cradle.

OPERATION

Refer to the instructions included with the HAI 38A00 Series Switch for set-up and operating instructions.